

UL LEVER BY LEVER EMTEK® KNOB BY KNOB ACTIVE MORTISE LOCK HOLE PREPARATION ─ 1-1/4 **─** (LEFT HAND)* -7/8 DOOR ø 1/2 ESCUTCHEON HOLE -7/8 1-3/16 THRU HOLE 1-7/8 ø 1-1/4 CYLINDER HOLE 5/8 1-1/8 **OUTSIDE ONLY** Ø 3/4 -3-1/2 1-3/16 **THUMB TURN** HOLE INSIDE ONLY MORTISE 4-7/8 6-3/8 3/4 3-3/8 3-11/16 **FOR LOCK** 1-1/2 LEVER SPINDLE HOLE THRU HOLE **(4**) 2-1/2 **─** 1-1/4 ø 1/2 1/4 DEEP -**ESCUTCHEON** FOR STRIKE PLATE, DUST BOX, THRU HOLE & UNDERSTRIKE PLATE (5)**DOOR JAMB PREP** 1/2 X 5/32 3/4 DEEP (X2) 1-1/4" DEPTH **RELIEF POCKETS** (FROM DOOR FACE) 3/16" DEPTH * NOTE: 8-1/2 X 11 COPY OF 1/4 DEEP -THIS TEMPLATE NOT TO SCALE. FOR BOX PLATE THIS TEMPLATE IS DESIGNED FOR 1-3/4 THICK DOOR. MORTISE BOX DEPTH: 4 DEEP FOR 2-3/4 BACKSET, ALL DIMENSIONS ARE IN INCHES. 3-3/4 DEEP FOR 2-1/2 BACKSET (FROM FACE OF DOOR) CHECK BACKSET BEFORE DRILLING! 2-1/2 BACKSET **2-3/4 BACKSE** € DOOR OF DOOR EDGE

IN4-MORTISLEVER-L 15C