

<p>1. Door Prep</p> <p>1" Dia. Edge Bores</p> <p>2-1/4"</p> <p>2-1/4"</p> <p>2-3/8" or 2-3/4"</p> <p>3-5/8" or 5-1/2"</p> <p>2-1/8" Dia. Bores</p> <p>1"</p>	<p>2. Door Jamb Prep</p> <p>1-1/8"</p> <p>2-3/4"</p> <p>1/8" Deep</p> <p>3/16" Deep</p>	<p>Dummy Function</p>
---	--	------------------------------

<p>3. Install Bolt and Latch</p>	<p>4. Install Outside Trim Plate</p> <div style="display: flex; justify-content: space-around;"> <div style="width: 45%;"> <p>Single Cylinder Inside</p> <p>Lever Shown</p> </div> <div style="width: 45%;"> <p>Outside</p> <p>Tailpiece Horizontal</p> <p>Knob Shown</p> </div> </div> <p style="text-align: center; border: 1px solid black; padding: 2px;">Plates and Lever/Knob vary depending on style</p>	
---	--	--

<p>5. Install Inside Trim Plate</p> <p>Double Cylinder Inside</p> <p>Tailpiece Vertical</p>	<p>6. Secure Lever/Knob</p> <p style="border: 1px solid black; padding: 2px;">After lock is installed, tighten set screw with hex wrench provided.</p>	<p>Optional Thru Bolts</p> <p style="border: 1px solid black; padding: 2px;">Thru bolts (provided) may be used on hollow doors instead of wood screws (also provided).</p>
--	---	---